

Stamp Mix

Cement Polymer Overlay Mix



APPLICATION GUIDE

CONCENTRATED MIX POLYMER

- 20-25 sq. ft. coverage per bag
- Polymer in Gallons - ½
- Water in Gallons - 1
- 60 lbs bag
- Thickness - 3/8"
- Color Pack - 1

MIXING

1. Resin Use as a Base Coat: Mix 1/2 gallon of stamp mix resin to 1 gallon of water with ½" drill. Apply with a ½" roller to area to be stamped, maintaining a "wet to wet" working area. (Base coat must be wet when stamp material is applied). If base coat dries out ahead of stamping, it must be re-applied to achieve a wet surface again.
2. Add color packs to KOVER KRETE™ STAMP RESIN mixing thoroughly.
3. Slowly add the dry bag mix until the desired consistency is achieved, adding more water if needed.
4. Always add the same amount of liquid to solid to achieve even color per batch.
5. Gauge rake to desired thickness 1/4" to ½" thickness

NOTES

1. For rough surfaces, a thicker mix can be made by adding sand to the dry mix.
2. Adjust mix consistency by adding dry or liquid to the mix, using the specified ratios.
3. For smaller amounts, use a smaller measuring container to maintain ratios.

4. Wet and dry component ratios may vary depending on moisture of sand and aggregates.

APPLICATION

1. New concrete should be cured for 28 days, with a minimum of 14 days.
2. Apply KOVER KRETE™ STAMP MIX directly over **WET** bond coat. Use a gauge rake to achieve desired thickness and immediately smooth with a round edge fresno. Build up edges with excess stamp mix. Dress edges by holding a square finish trowel against the edge of the concrete and running a concrete edger over it.
3. Finish rough areas with a fresno. Use KOVER KRETE™ LIQUID RELEASE on trowel to prevent sticking.
4. **ALL EXPANSION AND CONTROL JOINTS MUST BE HONORED!** Cut filled joints with a diamond blade saw within 24 hours, making sure the cut penetrates the stamp mix. Existing plastic expansion joints should be covered with a RE-COVER STRIP, and strapping tape.
5. Spray stamps and surface liberally with KOVER KRETE™ LIQUID RELEASE AGENT.
6. Begin stamping as soon as you can get on the surface without slipping. **DO NOT** allow the surface to set so that a pounder is necessary to imprint the surface. Clean off excess material as soon as you can walk on the surface in sock feet without damaging the surface.
7. Staining/coloring can be done the day after stamping.
8. Apply two coats of KOVER KRETE™ KLEAR GARD™ SB (solvent based) or WB (water based) SEALER, paying close attention to the expansion joints and edges of the deck.

Manufactured by

CONTRACT PACKAGING INC.

22 N. Dollins Avenue - Orlando, FL 32805

Tel. (407) 246-7797 - Fax. (407) 481-2261 - www.koverkrete.com